



ALL SWITCHES SHOWN IN FULL "ON" POSITION AS VIEWED FROM FRONT  
 "SELECTOR" SWITCH IS IN "TAPE HEAD" POSITION  
 "MAG PHONO FILTER" SWITCH (A) IS IN "OFF" POSITION  
 \*PUSH BUTTONS MAY BE CHANGED IF SUGGESTED BY CARTRIDGE MANUFACTURERS  
 OF SPEC. MICROPHONE CONTROLS

**SCHEMATIC**  
**HEATHKIT STEREO PREAMPLIFIER**  
**MODEL SP-2**  
**A CHANNEL PREAMPLIFIER AND POWER SUPPLY**