


**SCHEMATIC OF THE
HEATHKIT®
DIGITAL MPH AND MFG METER**

Model CI-107B


Copyright © 1975
Heath Company
All Rights Reserved

Part of 595-1731-03



NOTES:

1. ALL RESISTORS ARE 1/4 WATT, 10% UNLESS OTHERWISE INDICATED.
 2. RESISTOR VALUES ARE IN OHMS (Ω). K= 100, M= 1,000,000.
 3. CAPACITOR VALUES ARE IN MICROFARADS, (μ F) UNLESS OTHERWISE SPECIFIED. pF = PICO FARADS.
 4. \equiv THIS SYMBOL INDICATES CHASSIS GROUND.
 5. ∇ THIS SYMBOL INDICATES
 6. \circ THIS SYMBOL INDICATES
 7. \square THIS SYMBOL INDICATES
- * THESE COLORS MAY BE REVERSED OF THE SPEED TRANSDUCER IN




ATES CIRCUIT BOARD GROUND.

ATES WIRE CONNECTION TO BOARD.

ATES PLUG-IN CONNECTOR.

VERSED TO GET PROPER POLARITY
R IN YOUR CAR.



**SCHEMATIC OF THE
HEATHKIT®
DIGITAL MPH AND MFG METER**
Model CI-107B
Copyright © 1975
Heath Company
All Rights Reserved

Part of 595-1731-03

NOTES:

1. ALL RESISTORS ARE 1/4 WATT, 10% UNLESS OTHERWISE INDICATED.
2. RESISTOR VALUES ARE IN OHMS (Ω), K = 100, M = 1,000,000.
3. CAPACITOR VALUES ARE IN MICROFARADS (μ F) UNLESS OTHERWISE SPECIFIED. pF = PICO FARADS.
4. \equiv THIS SYMBOL INDICATES CHASSIS GROUND.
5. ∇ THIS SYMBOL INDICATES CIRCUIT BOARD GROUND.
6. \circ THIS SYMBOL INDICATES WIRE CONNECTION TO BOARD.
7. \square THIS SYMBOL INDICATES PLUG-IN CONNECTOR.

* THESE COLORS MAY BE REVERSED TO GET PROPER POLARITY OF THE SPEED TRANSDUCER IN YOUR CAR.